



Note:-

An alternative option to installing the membrane to maintain a straight profile within the liner wall, is to fix **PUDLO BW Membrane** to timber stop-end. Engineer to specify backfill material for structural requirements.

Prior to membrane and concrete application please consult with **PUDLO**.

Pour One - Wall to be cast in **PUDLO CWP Modified Concrete**.



Revision History

DATE	DESCRIPTION	REV.	DES.	Q.C.
17/09/18	Updated to September 2018 design standards.	A	LD	LL
26/06/18	First issue.	-	LD	LL

PUDLO Waterproof Concrete Systems

Wellington Way, Bourn Airfield
Cambridge, CB23 2TQ

Tel: +44 (0)1954 780687 Email: sales@pudlo.com
www.pudlo.com

DRAWING TITLE WALL TO SHEET PILE DETAIL	PROJECT -		
STATUS FOR INFO	SCALE 1:5 on A4		
DRAWING NUMBER PUDLO-TJD-BW-SS-019	REVISION A	SHEET No. 1 of 1	
CLIENT			

Note:-

This PUDLO detail is to assist with the installation of its products. The detail shows PUDLO CWP Modified Concrete and how PUDLO System accessories are to be installed. For site specific details and confirmation on extent of where PUDLO CWP Modified Concrete is used i.e. Overlay drawings, must be confirmed by structural engineers/contractor. Individual/Company responsibility for design of the structure must ensure that details shown on PUDLO drawings match the latest construction issue designs.

The information shown on this detail is given without obligation, or warranty **PRIOR** to consultation or communication with PUDLO/DBG Ltd.